

Traverse Wood Floor Cleaning & Maintenance Guide

Proper care and maintenance will keep your Traverse wood floors looking beautiful for years. Follow the guidelines below to protect your investment.

Daily & Routine Care

- Sweep or dust mop daily using a **soft-bristle broom** or **microfiber dust mop**.
- Remove grit and dirt promptly to prevent scratching.
- Use felt pads under furniture legs and replace them as needed.
- Keep pet nails trimmed.

Regular Cleaning (As Needed)

- Use **BONA® Pro Series Hardwood Floor Cleaner**.
- Spray cleaner lightly and clean using a **microfiber mop**.
- Clean in the direction of the wood grain.
- Allow floor to dry completely before walking on it.

DO NOT:

- Use water buckets, wet mops, or steam cleaners.
- Use vinegar, ammonia, oil soaps, waxes, or household cleaners.
- Allow standing liquid to remain on the floor.

Long-Term Maintenance

- Maintain indoor humidity between **40%–60%** to reduce expansion and contraction.
- Use area rugs or mats at entryways (non-rubber backing only).
- Avoid direct sunlight exposure; use curtains or UV-protective window treatments.
- Periodically rotate rugs and furniture to ensure even aging.

Following these guidelines will help preserve the appearance, durability, and warranty of your Traverse wood floor.